SPEEDLITE YN565EX **USER MANUAL** YONGNUO Before use, please READ this user manual carefully in order to ensure your safety. Keep it properly for reference in the future. I. Warning To avoid fire or electrical shock, do not expose this product to rain or moisture. To avoid short circuit, be sure the batteries contacts are securely packed and in accordance with local provision when handling the batteries. Please place the batteries and the parts which can be swallowed mistakenly away from children. Contact a doctor immediately when it occurs. To avoid possible injury to eyes, do not use the flash light in a short distance from the eyes. To avoid possible safety accident, do not use the flash light on the people who need a high degree of attention. Please take out the batteries and stop using immediately in case of below. • This product is dropped or shocked seriously and the inner part of the product is bared. • If the battery leaks corrosive liquids, please take out the battery with gloves. • The product gives off strange smell, smokes or heats. Do not disassemble or maintain this product. Touching the internal high voltage circuit will cause electric shock. Remove batteries during long periods of non-use. II. Features AWL SUPPORTED FOR N's & C's SYSTEM The YN565EX can be triggered by 580EX II, SB-900/800/700, 7D/60D/600D, Nikon c-command and ST-E2, and flashes as TTL mode as well as M/Multi mode. TTL FLASH WITH LARGE GUIDE NUMBER GN58@ ISO100, 105mm; which reaches the level of the mainstream hot shoe flashes, supports TTL/ M/Multi mode. MULTIPLE TRIGGER MODE SUPPORTED The YN565EX can be triggered by hot-shoe, flash command slave mode, optical S1, and S2 (pre-flash-canceled mode). SUPPORTS AUTO/MANUAL ZOOMING The YN565EX covers a focal length range of auto, and 24 to 105mm, supports full-frame/half-frame camera. COMPREHENSIVELY SUPPORTS TTL FUNCTIONS FEC, FEB, Rear-curtain sync, FE lock, Modeling Light, Canon camera menu accessable SUPER SPEED OF CHARGING RECYCLE It only takes 3 seconds to finish a charging cycle after a full level output, you can use external power pack to accelerate the charging speed once more. PROVIDES CHARGING SOCKET FOR EXTERNAL POWER PACK YN565EX provides charging socket for external power pack, to meet your higher demand for charging recycle. PC PORT PROVIDED YN565EX provides PC port, you can make the flash synchronously by connecting to the PC port. SOUND PROMPT SYSTEM Turn on the sound prompt function, different sounds indicate working situations help you focus on shooting. MODELING LIGHT FUNCTION Press down the camera's depth-of-fired preview button, the YN565EX will send out continuous flash lasting one second. ADVANCED SETTINGS ON FLASH The YN565EX supports advanced settings; you can customize the unit according to your shooting preferences. **AUTOMATIC SETTINGS SAVING** YN565EX can save the current settings automatically. LCD PANEL USER INTERFACE WITH SUPER GELIVABLE METAL HOT-SHOE STAND III. Quick Start If you don't have much time to read the whole user manual, we advise you to read this section. 1. Please avoid the excessive use of the output with maximum power. It can effectively extend the service 2. You can understand the function of each button by pressing them and observing the displayed content. 3. Keeping [ZOOM] button under pressed can enter off mode SL (cn or c, n separately) /S1/S2. 4. Long press on [Fn] button to set the function of advanced option of speedlite. See the section of "advanced setting" for the content. 5. Operate the YN565EX through function setting of external speedlite on the menu of Canon camera. 6. Press the [UP], [DOWN], [LEFT] and [RIGHT] buttons to adjust the parameters of speedlite quickly at the current mode. For some parameters, the [OK] button in the center is needed to be pressed for setting. 7. This product provides ETTL/M/MULTI mode. It can be switched through [MODE] button. IV. Nomenclature 1. Reflection board 2. Wide-angle diffuser 3. Flash head 4. External power pack socket (It can be connected to the SF-18C or SF-17C external power pack) 5. PC port (for input) 6. Contact cover 7. Wireless sensor 8. Battery chamber's cover (6) 9. AF-assist beam emitter (10)10. Locking ring (11) 11. Hot shoe stand 12. Hot shoe contact (13)(12) 13. Sound port MODE ZOOM/Z PILOT ON/OFF 14. LCD panel: It will display the status of function settings. 15. Rear-curtain sync hotkey: The speedlite will be switched between rear-curtain sync and front-curtain sync in circle for each press. 16. ZOOM button: It is applied to set focal length coverage of speedlite and relevant parameters of slave unit. Use the [ZOOM] and [LEFT], [RIGHT], [UP], [DOWN] and [OK] button for operation. 17. Power switch: The power of the speedlite can be turned on or turned off by holding this button for 18. Select/Setting button group: Buttons of multi functions include LEFT, RIGHT, UP, DOWN and OK buttons; you can adjust output, FEC, FEB, Stroboscopic flash count, Stroboscopic flash frequency, zooming setting, slave units, channel and slave groups. 19. Mode switch button: Under the normal flash, the mode of the speelite will be switched among the ETTL/M/MULTI in circle for each press; and under the wireless flash, long press on this button locks the speedlite in M and MULTI mode. 20. Illumination/Advanced options button: A short press will turn on or turn off the LCD panel illumination light, a long press on the button conducts advanced option setting of speedlite. 21. Charging indicator / Test button: The lighting of red light shows that charging process is finished and flash can be used; the lighting of green light shows that it is in charging or a shortage of power; the alternate flashing of the red and green lights shows overheat protection, please wait for about 3 minutes to cancel the protection before continuing use. If you press this test button (PILOT), the speedlite will give a test flash. 22. Flash exposure confirmation indicator: If a standard exposure was obtained, the flash exposure confirmation indicator will light for 3 seconds. 液晶屏 Manual flash output level < Manual zoom Flash exposure compensation amount FEB compensation amount Aperture FEB status Stroboscopic flash count Stroboscopic flash frequency **FEB** Manual flash 1/3-stop increment indicator Advanced setting ETTL autoflash Zoom focal length Advanced option NO. < M/Multi> Manual mode/ MULTI mode Auto zoom ∠ for image size MZoom 188mm = +8 8/1880188+18.8_{Hz} 1234 SLAVE CIn 🕪 3 4 6 9 13 18 10 15 20 30 40 60 Slave group Advanced setting Flash range scale ⟨₩⟩ FEC Indicator <(i0≯>-Indicator Rear-curtain sync Flash mode Slave flash : Channel V. Installation Instruction 1. Install Batteries Slide the batteries chamber's cover in the direction of the arrow. Insert the batteries according to the label inside battery chamber. Make sure the direction of the batteries' polarity is correct. Close the battery chamber cover in the direction of the arrow. 2. Attaching to the Camera Loosen the locking ring by turning it in the direction of the arrow. Slip the speedlite hot shoe stand into the camera hot shoe stand until it stops. Turn the locking ring in the direction of the arrow tighten. To detach the speedlite, loosen the locking ring by turning it in the opposite direction. VI. Basic Functions 1. Basic Operations Operation of the buttons: Component Operation Power switch of the flash light. The power of the flash light can be turned on or turned off by holding this button [Power Switch] It is suggested that the battery shall be taken out after the power of the flash light is closed through this button. A short press on this button makes the speedlite enter electric zoom setting state. Press [LEFT] [RIGHT] or [UP] [DOWN] buttons to adjust different focal length (auto, 24, 28, 35, 50, 70, 80, 105mm)... [ZOOM] button A long press on this button makes the speedlite enter slave unit setting state, you can set it at SL (cn or c, n separately) and S1/S2. Then press [OK] button to confirm the setting. The speedlite will be switched between rear-curtain sync and front-curtain sync in circle for each press. [Rear curtain sync] hotkey Under the normal flash, the mode of the specific will be switched among the ETTL/M/MULTI in circle for each [MODE] button press; and under the wireless flash, long press on this button locks the speedlite in M and MULTI mode. Illumination/advanced A short press will turn on or turn off the LCD panel illumination, hold the button to go into the status of advanced option] button Used as the button to adjust slave unit, zoom range, flash brightness, Exposure Compensation, stroboscopic flash [LEFT] [RIGHT] and times, stroboscopic flash frequency. See the subsequent chapter for relevant operation. [OK] button You can set exposure bracketing and zoom range. Under the TTL mode, you can operate [up] and [down] button to [UP] [DOWN] button set the exposure bracketing of speedlite. It should be used with [ZOOM] button to set range zoom. [PILOT] button Press this test button and the speedlite will test flashing in current output level; under the dormancy state, you can 2. Power-on and Power-off The power of the flash light can be opened or closed by holding this button for 2 seconds. It is suggested that the battery shall be taken out after the power of the flash light is closed through this button. After opening the power switch of the flash, the flash will fetch the setting state saved in the closedown last time, the charging indicator is green, which indicates the flash is available. If the charging is not completed within 20 seconds, and <PL> will be displayed on LCD panel, the flash will automatically shutdown. Then you need to replace with new batteries. You may press the testing button PILOT to test whether the flash works normally. After use, hold the power switch for 2S to power off. 3. ETTL MODE Just set the camera's shooting mode to [AV] (aperture-priority AE), [TV] (shutter-priority-AE), or [M](manual), and you can use ETTL autoflash. Under the ETTL mode, YN565EX supports FEC, FEB, Rear-sync, FEV, Modeling, Canon camera menu accessable. 4. M mode Zoom 35mm You can set the flash output from 1/128 to 1/1 full power in 1/3-stop 1/ ; increments. Press the [LEFT] [RIGHT] button to adjust the output directly. M **★** Press [MODE] button and the <M> will display on LCD panel. * Press [LEFT] and [RIGHT] button to adjust output level, you can fine tune the power output of the flash by [UP] and [DOWN], the step size is 1/3ev. Zoom 35mm * Press the shutter button halfway, and check that the subject is within the effective range displayed on the LCD panel. M NOTE: The effective range don't display on the LCD panel before charging is finished. 0.5 0.7 1 1.5 2 3 4 6 9 13 18 m 1.7 2.3 4 5 7 10 15 20 30 40 60 ft 5. MULTI mode With MULTI mode, a rapid series of flashes is fired. It can be used to capture multiple images of a moving subject in single photograph. The speedlite will flash according to the output power, flash times Zoom 35mm and frequency you set. Use [LEFT], [RIGHT] and [OK] buttons to lHz adjust output power, flash times and frequency. The adjustment MULT scope of output frequency is 1/128-1/64-1/32-1/16-1/8-1/4, the scope of flash times is from 1 to 100 (if the flash time is set as --, 0.5 0.7 1 1.5 2 3 4 6 9 13 18 m 1.7 2.3 4 5 7 10 15 20 30 40 60 ft it flashes according to the default setting.) and the scope of flash frequency is 1 to 100. Adjustment method: please press [OK] button to select setting items (flash) and use the [LEFT] and [RIGHT] buttons to adjust the parameters. After the setting is completed, press [OK] button to confirm the setting. NOTE: The charging speed of flash light is slow under the situation that the electricity quantity of the battery is insufficient, which may cause the occurrence of the high-frequency flash. Please reduce the flash frequency or change new battery under this situation. 6. S1/S2 mode These two modes are suitable for manual flash environment and TTL flash environment respectively. Under these two modes, the way to adjust the output level is like the way in M mode. When using S1/S2 mode, you can rotate the flash head to make the wireless triggering sensor face with the master flash. Setting method: Hold press the [ZOOM] button, and then press [LEFT] [RIHGT] button to select S1 or S2. S1 mode: It will work with the first trigger of master flash synchronously; the master flash should be set at manual flash. S2 mode: It is also called "pre-flash cancel mode", it can neglect the pre-flash given by TTL flash, and therefore, it can support the main flash working in TTL mode. The following situation shall be avoided when the S1 and S2 modes are used: the red eye reduction function of the main light is used; the order mode (nikon) or wireless mode (canon) of the main light is used; the ST-E2 is used as the flash controller. Otherwise, please set the speedlite as SL (see "wireless flash system" for detail). 7. Menu Access of Camera (only for the more recent Canon models) You can control the speedlite by accessing to camera menu on the recent canon models which support ETTL. On the Flash Control Menu, you can set some parameters through "External flash func. setting" and "External flash C. Fn setting", for example, Flash mode, Shutter sync, FEB, Flash exp. comp, Zoom, Wireless set, and advanced setting etc. Whether in any mode, you can press PILOT button to test if the speedlite flash normally. When testing the flash, the speedlite will give flash at relevant output level in accordance with the chosen output power setting. 9. Power Saving Mode YN565EX provides shrinkable power-saving mode; this power-saving mode can set through long press on[Advanced option] button. Long press the [Advanced option] to enter the setting state and select the option with number 01 through [up] and [down] buttons. When pressing the [right] button to set the state as SL EP - -, this means to disable the function of "automatic power off". When it is set as SL EP on, this means that the function of "automatic power off" is enabled, the following table lists the power-saving mode that is set through advanced option. NO. Scope of Setting options Power saving mode Application Power saving mode is closed 01 All modes SL EP Power saving mode is open on SL/S1/S2 10 60 Power automatic off of the slave unit is 60 minutes SL Sd 10 Power automatic off of the slave unit is 10 minutes SL/S1/S2 11 1H Slave auto power off cancel within 1 hours SL OFF 8H Slave auto power off cancel within 8 hours 3/5/10/30/1H/2 Sleep after idle time of 3 minutes/5 minutes/10 minutes/30 15 Others SE OFF H/3H/5H minutes/1 hour/2 hours/3 hours/5hours. After it enters the sleep state, it powers off automatically after keeps the same idle time Under the dormancy situation, <SE> will be displayed on LCD panel, you can awake the speedlite by pressing any button. 10. Overheating Protection If the speedlite is used too frequently, the overheating protection function will be triggered, the red and green lights of the charging indicator will blink alternatively, and <O.H> will be displayed on LCD panel, the speedlite will be locked. In such case, please wait for about 3 minutes to cancel the protection before continuing use. Please try to use 1/4 output or lower when rapid shooting is needed to prevent the effect on the shooting. 11. ZOOM Setting the Flash Coverage Auto Zoom: Press the [ZOOM] button to adjust the flash Zoom 35mm ETTL overage, if <M> is not displayed, the flash coverage will be set automatically (35mm for default coverage). Attaching the speedlite to the camera, the flash coverage will set automatically to match the lens focal length. 0.5 0.7 1 1.5 2 3 4 6 9 13 18 m 1.7 2.3 4 5 7 10 15 20 30 40 60 ft Manually set the zooming position: Press the [ZOOM] button to MZoom 24mm **ETTL** adjust the flash coverage, if <M> is displayed, pressing the [LEFT] [RIGHT] or [UP] [DOWN] buttons, the coverage focal length of the flash will switch in circle of (24, 28, 35, 50, 70, 80, NOTE: Using wide-angle-diffuser, the flash coverage will then be extended for 14mm. 12. Sound prompt When the sound prompt function is activated the speedlite will give out different sound to indicate the working state. Sound prompt can be set through function of advanced option. The method is: long press on the [Advanced option] button until it enters the advanced option setting state. Select item 14 through [UP] and [DOWN] buttons and use [LEFT] and [RIGHT] buttons to set sound disabled or sound enabled. <14 S0 nd on/-->. This means that the sound prompt is enabled or disabled. When the sound prompt is enabled, see the following table for the meaning of sound. The sound form Meaning Operation a. A standard flash was obtained; Tick twice Normal b. The speedlite is started; Three ticks, two times Adjusting exposure compensation or changing The exposure may be over shooting condition Tick — tick — tick The exposure may be excessive Adjusting exposure setting or shooting condition Tick—tick a. The power is not enough; Replace the batteries, waiting for the completion b. The speedlite is in the charging or of charging or the protection is canceled twice-tick twiceoverheating protection state; Tick a long sound Normal The speedlite is fully charged and can be used. Tick-tick-tick Sound prompt before turn off Normal 13 Modeling Light Function Press down the camera's depth-of-fired preview button, the YN565EX will send out continuous flash lasting one NOTE: Do not fire the modeling flash more than 10 consecutive times. If you fire the modeling flash 10 consecutive times, allow the speedlite to rest for 10 to 15 minutes to avoid overheating and deteriorating the flash head. 14. PC synchronous port (for input) By connecting to the PC port synchronous port, you can make the flash synchronously. 15. Automatic setting saving The speedlite will automatically save the current setting in order to let you have a simpler use next time after boot. VII. Wireless Flash System YN565EX has wireless remote flash systems as slave unit, the YN565EX can be triggered by 580EX II, SB-900/800/ 700, 7D/60D/600D, Nikon c-command and ST-E2, wireless TTL or manual lighting can be achieved. cn: Indicating that it can receive wireless signal from Canon system as well as Nikon system at the same time. c: Indicating that it can only receive wireless signal from Canon system, avoiding Nikon system. n: Indicating that it can only receive wireless signal from Nikon system, avoiding Canon system. Any flash exposure compensation, FEB, FE lock, manual flash, and stroboscopic flash settings set with the master unit will be automatically transmitted to the YN565EX. Even with multiple YN565EXs, all of them will be controlled in the same way via wireless signal. 1. Master unit setting To use 580EX II, SB-900/800/700, 7D/60D/600D with built-in commander mode, Nikon c-commander and ST-E2. For the setting method, please refer to your master instructions. 2. Slave unit settin As the slave unit, when YN565EX is used, the wireless option of speedlite is set as SLAVE. Setting method: long press on ZOOM for 2 seconds to make the OFF flash on the LCD screen, this means that it is in the setting state. Use [LEFT] and [RIGHT] buttons to select SL. The LCD screen display on when [OK] button is pressed at this moment. This means that it receives the wireless signal from Canon and Nikon at the same time. Press ZOOM button again and <c n>, < CH > or < A > will flash. This means that it enters setting state of Canon or Nikon wireless option, communication channel or slave unit. At this moment, use [LEFT] and [RIGHT] buttons to set slave unit c/n separately, number of communication channel (1, 2, 3, 4) or slave group (A, B, C), then press [OK] button to confirm setting. Prompt: When does it need to set c or n under the off camera mode instead of cn mode? When other cameraman uses off camera control in the environment, and you don't want to be bothered. Separate setting of c or n may slightly improve the correctness of flash control. 3. Multi-Speedlite, Wireless lighting configurations You can create two or three slave groups to make shooting effect better meet your requirements, and set flash ratio for ETTL autoflash shooting of master, as well as manual flash output, frequency flash etc. Wireless flash of two slave units made up by YN565EX * Wireless option setting: cn, c, n for operation * Communication Channel setting: 1, 2, 3, 4 Outdoors * Groups setting: Set one YN565EX as group A, and set the other one as group B. * Master unit setting: Set the communication channel, Set the Indoors flash ratio of master unit A: B or A: B C. You can conduct flash shooting. Wireless flash with three YN565EX speedlites * Wireless option setting: cn, c, n * Channel setting: 1, 2, 3, 4 Groups setting: Set three YN565EX speedlites as group A. Outdoors group B and group C respectively. * Setting master and shooting: Please select the ratio<A: B C>. Press the test button of master to test whether the flash works Indoors normally; if the flash does not fire, adjust the slave unit's angle toward the master unit and distance from the master unit. NOTE: If ratio <A: B> is set, the slave unit in group C will not fire. If you have the slave group set to <A> for three slave units, all three slave units will be controlled as if they were one speedlite in slave group A. Slave group A 4. Setting Manual Flash and Stroboscopic Flash with Wireless You can also lock the flash mode when YN565EX is used as slave unit. Zoom 35mm Manual flash: Press the [MODE] button for 2 sec. or longer until <M> display, then you can set the output level by pressing M [LEFT] [RIGHT] [UP] [DOWN]. Zoom 🗦 🗦 mm Stroboscopic flash: Continue to press the [MODE] button Hz until <MULTI> display, then you can set the output level, Multi number offlashes, and firing frequency by pressing [OK] [LEFT] [RIGHT]. 5. Shooting Examples with Wireless Flash System * Master unit: 580-II, SB-900/800/700, 7D/60D/600D with built-in commander mode, Nikon c-commander and ST-E2. * Slave unit: YONGNUO EX series flash, you can create three slave groups at all. * Use the mini flash stand (tripod socket provided) to prop up the YN565EX speedlite. * Swing the YN565EX so that its wireless sensor faces the master unit. * Indoors, the wireless signal can also bounce off the wall so there is more leeway in positioning the YN565EX(s). * After positioning the YN565EX(s), be sure to test the wireless flash operation before shooting. Don't place any obstacles between the master unit and slave unit(s). Obstacles can block the transmission of wireless signals. 2.5m Outdoors 15m Indoors VIII. The Advanced Application 1. Ultra-long-range Wireless Flash YN565EX can receive remote wireless signal. The longest distance used indoors is 25 meters and the longest distance used outdoors is 15 meters. Please note that the YN565EX's wireless sensor should be faced to master unit, and make sure it is within the effective range of transmission. 2. Flash Exposure Compensation You can use the exposure compensation function of the camera to compensate flash output so as to make shooting effect better meet your requirements. You can also make compensation of flash brightness with the [LEFT] [RIGHT] button within the range of ±5ev, with the precision of 1/3ev. Every press the button, the compensation setting will be displayed on LCD panel. NOTE: For Canon version, please note that this compensation setting will override the exposure compensation setting on the camera. 3. Rear- curtain Sync You can use slow-speed shutter to produce trailing smear for the object and the flash light will flash at the moment when the shutter is going to be shut, which means the rear-curtain sync function (For the rear-curtain sync setting, refer to your camera manual for setting). You can turn on or turn off the rear-curtain sync by pressing the [rear-curtain sync] hotkey on panel of YN565EX. NOTE: When YN565EX is used as slave unit, the rear-curtain sync function cannot be set. 4. Exposure Bracketing (FEB) The FEB function is set on the camera or speedlite. For the specific setting method, refer to your Camera Instructions. After the FEB is set, after 3 photos are taken, exposure compensation will be made automatically in the sequence of, over". This function helps you improve the success rate of photo taking. for example, "normal under The setting method on the YN565EX speedlite: Press the [UP] [DOWN] button to adjust the exposure bracketing amount. NOTE: For FEB, set the camera's drive mode to single shooting. Be sure the flash is ready before shooting. 5. FE Lock (Canon) To use this function, cover the subject for which flash exposure will be locked at the center of the viewfinder of camera, press the button <*> of the flash exposure lock, and the flash light will pre-flash and the camera will calculate the appropriate flash output data. Now you have some time for decomposition, after which, you can take photo. (The function can be used only when it is supported by your camera. For the setting method, refer to your Camera 6. FV Lock (Nikon) Set the AE-L/AF-L function as FV Lock on the camera before using this function. At this time, you can aim at your desired object in the viewfinder and then press the AE-L key or AF-L key, in such case, the flash light will pre-flash to get the reading of flash exposure for the object; after you have confirmed the scene frame, press the shutter. (This function can only be available when your camera supports it; for the setting of AE-L and AF-L, refer to your camera manual). 7. Advanced Setting The YN565EX provides advanced settings, you can customize speedlite feature to suit your shooting preferences. Set the advanced settings through hotkey of speedlite or menu accessable. Setting method of hotkey: Press the [advanced setting] button for 2 sec. or longer until the item to be set displays; for example, <01 SL EP --> is displayed. Menu accessable can only be available when your camera supports it; for the setting method, refer to your camera manualHold the [OK] button to recover the default settings. The meanings of the items can be found in the table below: 00 • Fn NO.: 00 • Effective flash distance: effective flash distance takes C.Fn m as unit or ft as unit. 0.5 0.7 1 1.5 2 3 4 6 9 13 18 m 1.7 2.3 4 5 7 10 15 20 30 40 60 ft 01 • Fn NO.: 01 SL EP 0 0 • SL EP on: Auto power off is enabled Cim • SL EP --: Auto power off is disabled • Fn NO.: 03 83 Fb [L 0 0 • Fb CL on: FEB auto cancel is enabled C.In • Fb CL --: FEB auto cancel is disabled • Fn NO.: 04 Fb 0-+ • Fb 0 -+: Sequence of FEB is " $0 \rightarrow -- \rightarrow +$ " C.I.n • Fb -0+: Sequence of FEB is " $-\to 0 \to +$ " 80 • Fn NO.: 08 AF 0 1 • AF L on: AF-assist beam firing is enabled C.I n • AF L --: AF-assist beam firing is disabled •Fn NO.: 09 09 AP 5- 8 1 • AP S – A1: Automatic identification is enabled C.I n AP S − --: Disable • Fn NO.: 10 10 50 10 • SL Sd 60: Power automatic off of the slave unit is 60 minutes C.Fn • SL Sd 10: Power automatic off of the slave unit is 10 minutes • Fn NO.: 11 SLO FF H •SL OFF 8H: Slave auto power off cancel within 8 hours C.In • SL OFF 1H: Slave auto power off cancel within 1 hour • Fn NO.: 14 • SO nd on: Sound prompt function is enabled C.Fn • SO nd --: Sound prompt function is disabled • Fn NO.: 15 SEO FF 5 • SEOFF 3/5/10/30/1H/2H/3H/5H: Keeping idle for 3/5/ C.Fn 10/30 minutes or 1/2/3/5 hours will enter the dormancy mode. 15 EL ER • Fn NO.: 16 C.In • CL EA --: Recover the default settings NOTE: The option with Fn number from 00 to 13 can be set through "Flash C. Fn settings" of camera menu; the option with number 02, 05, 06, 07, 12, 13 are be disabled. 8. The use of external charging box You can buy YONGNUO external charging boxes like SF-18C or SF-17C and connect it to the charging port of the speedlite. After flash, the charging box will charge the speedlite. 9. High-speed continuous shooting The flash can realize the high-speed continuous shooting function. Please set the camera in the continuous shooting form and then shoot. Please turn off the sound prompt function when using high-speedlite continuous shooting. Please note: The number of photos that can be continuous shot is related with the output level. Please use the fully charged battery. 10. Reflection Flash Bounce flash means to take photos by making flash light head aimed at wall or ceiling and using the light reflected back from the ceiling or wall to light the desired object, so that the shade behind the object can be decreased to get more natural shooting effect. If the wall or ceiling is too far, the bounce flash may be too weak to get enough exposure. The wall or ceiling should be even and white in order to get efficient reflection; if the reflection surface is not white, color cast may appear in photo. 11. Use Reflection Board to Take Photos With the reflection board flash, draw the reflection board and the wide-angle diffusion board out from the light head at the same time and then push the wide-angle diffusion board back. In such case, if this product is being used to take photos, it will produce a highlighted point on the eyes of the subject and thus make the eyes charming (catch light). This function can reach optimal effect when the flash head is up 90°. 9. Use Wide-angle Diffuser Pull out the wide-angle diffusion board, push back the reflection board and arrange them as per the figure; in such case, the flash scopes will extent to 18 mm and the flash effect will be softer and more natural. IX. Specifications Circuit design Insulated Gate Bipolar Transistor (IGBT) Guide No. 58 (ISO 100, 105mm) Flash mode TTL、M、MULTI Wireless trigger N's & C's wireless system/S1/S2 pre-flash-canceled mode Wireless triggering distance 20~25m indoor, 10~15m outdoor Slave groups 3 (A, B, and C) Channels auto, 24, 28, 35, 50, 70, 80, 105mm Zoom range Vertical rotation angle -7~90 degrees 0~270 degrees Horizontal rotation angle 4×AAsize batteries (Alkaline or Ni-MH are usable) Power supply 100~1500 times (AA alkaline cell used) Lighting times approx 3s (AA alkaline cell used) Recycle time Color temperature 5600k Flash time $1/200s\sim1/20000s$ Flash control 8 levels of output control (1/128~1/1), 22 levels of fine tuning External interface hot shoe, PC port and eternal charging port YONGNUO external charging boxes like SF-18C, SF-17C External power Additional features Rear-curtain sync, FEC, FEB, FEV, modeling flash, manual zoom, auto zoom, sound prompt, advanced setting, automatically saving setting, PC port, power saving mode and over heat protection 60×190×78mm (Extended state) Dimensions 380g Net weight Accessories Flash light (1), protecting bag (1), mini stand (1) and manual (1) Guide Number of different focal length range (at ISO 100, in meters / feet) Flash Output Flash Coverage (mm) 50 105 14 24 28 70 80 1/1 15/49.2 28/91.9 30/98.4 39/127.9 42/137.8 50/164 53/173.9 58/190.3 27.6/90.7 37.5/123 41/134.5 1/2 35.4/116.1 10.6/34.8 19.8/65 21.2/69.6 29.7/97.4 14/45.9 1/4 7.5/24.6 15/49.2 19.5/64 21/68.9 25/82 26.5/86.9 29/95.1 1/8 5.3/17.4 9.9/32.5 10.6/34.8 13.7/45.2 14.8/48.6 17.7/58.1 18.7/61.4 20.5/67.3 1/16 3.8/12.5 7/23 7.5/24.6 9.7/32 10.5/34.4 12.5/41 13.3/43.6 14.5/47.6 1/32 2.7/8.9 4.9/16.1 5.3/17.4 6.9/22.7 7.4/24.3 8.8/28.99.4/30.8 10.3/33.8 1/64 1.9/6.2 3.5/11.5 3.8/12.5 4.9/16 5.3/17.4 6.3/20.7 6.6/21.7 7.3/24 1/128 1.3/4.3 2.5/8.2 2.7/8.9 3.5/11.4 3.7/12.1 4.4/14.4 4.7/15.4 5.1/16.7 X. Possible problems during use and solutions 1. The YN565EX can't flash * Check whether the batteries are installed in the correct orientation: Please install the batteries in the correct orientation. * Check whether the speedlite is attached to the camera: Slip the speedlite hot shoe stand into the camera hot shoe stand hard. * Check the hot shoe contact: Clean the contacts. * Check whether the batteries are exhausted: If the charging is not completed within 20 seconds, the flash will automatically shutdown. Then you need to replace with new batteries. 2. YN565EX can't work as slave unit * Check the slave unit setting: The YN565EX must be set to SLAVE. * Check the slave unit's situation: Please position the YN565EX(s) within the master's wireless transmission range. Adjust the slave unit's angle toward the master unit and distance from the master unit. Note: Setting the slave unit as separate c or n can slightly improve the success rate of flash. 3. Underexposure or overexposure of photo * Check whether the shutter, aperture and sensitivity (ISO) of camera are set too close to the limit of flashing, or whether the exposure compensation, exposure bracketing and other settings relative with flashing are correct. * Because of the differences among different types of cameras and the personal preference, you may meet the whole overexposure or underexposure when using this product, and so try to adjust it through the flashing compensation or exposure compensation. 4. Is the FEB exposure range set anew every time? You can access FEB setting through camera menu or lock FEB setting through Fn advanced option setting to avoid that FEB will cancel automatically when completing three shooting tasks. The number of setting option is 03. It is ok to set the "FEB auto cancel" disabled. 5. Underexposure of photo Please check whether your speedlite is set with exposure bracketing and the exposure order is " $-\rightarrow 0\rightarrow +$ ". You can access Fn advanced option through camera menu to set the order of exposure bracketing as "0→− or enables "FEB to cancel". 6. Vignetting appears in photos or only part of the subject is illuminated? This product has a designed light head zoom range of 24-85 mm, and is currently not compatible with full frame camera system. You may pull out the wide-angle diffuser to widen the flash range. 7. The state of YN565EX is abnormal. Please try to turn off the power supply YN565EX and camera. After YN565EX is installed on the hot shoe of camera, turn on the power supply again. If it is still unusual, please replace the batteries. Updated version of this manual can be got from http://www.yongnuo.com.cn/usermanual/downloadIndex.htm The functions of this manual are based on test conditions of our company. Further notice will not be given if the design and specifications change. The YONGNUO logo in this manual includes the registered trademark or trademark of SHENZHEN YONGNUO PHOTOGRAPHY EQUIPMENT Co., Ltd in China or/and other countries (regions). All other trademarks are the property of their respective owners. SHENZHEN YONGNUO PHOTOGRAPHY EQUIPMENT Co., Ltd 2-A511 Saige Science & Technology Park, North Huaqian Rd, Futian District, Shenzhen, China TEL: (086)0755-83762448 Email: technicalsupport@hkyongnuo.com FAX: (086)0755-83762765 Website: www.hkyongnuo.com